

Voltage monitoring in 3-phase mains

G2YM...VL20

Monitoring relays - GAMMA series Multifunction Fault latch Connection of neutral wire necessary Supply voltage selectable via power modules 2 change-over contacts Width 22.5mm Industrial design



Technical data

1. Functions

Voltage monitoring in 3-phase mains (phase voltage) with adjustable thresholds, adjustable tripping delay and the following functions which are selectable by means of rotary switch:

OVER	Overvoltage monitoring
OVER+LATCH	Overvoltage monitoring and fault latch
UNDER	Undervoltage monitoring
UNDER+LATCH	Undervoltage monitoring and fault latch
WIN	Monitoring of window between Min and Max
WIN+LATCH	Monitoring the window between Min and Max and
	fault latch

0.1s

threshold

Adjustment range

10s

indication of supply voltage

indication of relay output

indication of tripping delay of the corresponding threshold

indication of failure of the corresponding

2. Time ranges

Start-up suppression time: Tripping delay:

3. Indicators

Green LED ON: Red LED ON/OFF:

Red LED flashing:

Yellow LED ON/OFF:

4. Mechanical design

Self-extinguishing plastic housing, IP rating IP40 Mounted on DIN-Rail TS 35 according to EN 60715 Mounting position: any

Shockproof terminal connection according to VBG 4 (PZ1 required), IP rating IP20 Tightening torque: max. 1Nm

Terminal capacity:

- 1 x 0.5 to 2.5mm² with/without multicore cable end
- 1 x 4mm² without multicore cable end
- $2 \ x \ 0.5$ to $1.5 mm^2$ with/without multicore cable end
- 2 x 2.5mm² flexible without multicore cable end

5. Input circuit

Supply voltage: 12 to 400V AC

Tolerance: Rated frequency: Rated consumption: Duration of operation: Reset time: Residual ripple for DC: Drop-out voltage: Overvoltage category: Rated surge voltage: terminals A1-A2 (galvanically separated) selectable via power modules TR2 according to specification of power module according to specification of power module 2VA (1.5W) 100% 500ms ->30% of the supply voltage III (in accordance with IEC 60664-1)

6. Output circuit

2 potential free change-over contacts Rated voltage: 250V AC Switching capacity: 750VA (3A / 250V AC) If the distance between the devices is less than 5mm!

4kV

Switching capacity: If the distance between the Fusing: Mechanical life: Electrical life: Switching frequency: Overvoltage category: Rated surge voltage:	1250VA (5A / 250V AC) the devices is greater than 5mm! 5A fast acting 20 x 10 ⁶ operations 2 x 10 ⁵ operations at 1000VA resistive load max. 60/min at 100VA resistive load (in accordance with IEC 60947-5-1) III (in accordance with IEC 60664-1) 4kV
7. Measuring circuit Fusing: Measured variable: Input: 66V AC 132V AC 230V AC Overload capacity: 66V AC 132V AC 230V AC Input resistance: 3N~ 115/66V 3N~ 230/132V 3N~ 400/230V Switching threshold Max: Min: Overvoltage category:	max. 20A (in accordance with UL 508) AC Sinus (16.6 to 400Hz) terminals N-L1, N-L2, N-L3 (G2YM115VL20) terminals N-L1, N-L2, N-L3 (G2YM230VL20) terminals N-L1, N-L2, N-L3 (G2YM400VL20) 125V AC (G2YM115VL20) 250V AC (G2YM115VL20) 250V AC (G2YM400VL20) 150kΩ (G2YM115VL20) 270kΩ (G2YM230VL20) 470kΩ (G2YM400VL20) -20% to +30% of U _N -30% to +20% of U _N III (in accordance with IEC 60664-1)
Rated surge voltage: 8. Accuracy Base accuracy: Frequency response: Adjustment accuracy: Repetition accuracy: Voltage influence: Temperature influence:	4kV ≤3% (of maximum scale value) -10% to +5% (at 16.6 to 400Hz) ≤5% (of maximum scale value) ≤2% - ≤0.05% / °C
 9. Ambient conditions Ambient temperature: Storage temperature: Transport temperature: Relative humidity: Pollution degree: Vibration resistance: Shock resistance: 	-25 to +55°C (in accordance with IEC 60068-1) -25 to +40°C (in accordance with UL 508) -25 to +70°C -25 to +70°C 15% to 85% (in accordance with IEC 60721-3-3 class 3K3) 3 (in accordance with IEC 60664-1) 10 to 55Hz 0.35mm (in accordance with IEC 60068-2-6) 15g 11ms (in accordance with IEC 60068-2-27)

Functions

For all the functions the LEDs MIN and MAX are flashing alternating, when the minimum value for the measured voltage was chosen to be greater than the maximum value. If a failure already exists when the device is activated, the output relays remain in off-position and the LED for the corresponding threshold is illuminated.

Overvoltage monitoring (OVER, OVER+LATCH)

When the measured voltage of one of the phases exceeds the value adjusted at the MAX-regulator, the set interval of the tripping delay (DELAY) begins (red LED MAX flashes). After the interval has expired (red LED MAX illuminated), the output relays switch into off-position (yellow LED not illuminated). The output relays again switch into orn-position (yellow LED illuminated), when the measured voltage of all the phases falls below the value adjusted at the MIN-regulator (red LED MAX not illuminated). If the fault latch is activated (OVER+LATCH) and the measured voltage of one of the phases remains above the MAX-value longer than the set interval of the tripping delay, the output relays remain in the off-position even if the measured voltage of all the phases falls below the value adjusted at the MIN-regulator. After resetting the failure (interrupting and re-applying the supply voltage), the output relays switch into on-position and a new measuring cycle begins with the set interval of the start-up suppression (START).



Undervoltage monitoring (UNDER, UNDER+LATCH)

When the measured voltage of one of the phases falls below the value adjusted at the MIN-regulator, the set interval of the tripping delay (DELAY) begins (red LED MIN flashes). After the interval has expired (red LED MIN illuminated), the output relays switch into

off-position (yellow LED not illuminated). The output relays again switch into on-position (yellow LED illuminated), when the measured voltage of all the phases exceeds the value adjusted at the

MAX-regulator. If the fault latch is activated (UNDER+LATCH) and the measured voltage of one of the phases remains below the MIN-value longer than the set interval of the tripping delay, the output relays remain in the off-position even if the measured voltage of all the phases exceeds the value adjusted at the MAX-regulator. After resetting the failure (interrupting and re-applying the supply voltage), the output relays switch into on-position and a new measuring cycle begins with the set interval of the start-up suppression (START).



Window function (WIN, WIN+LATCH)

The output relays switch into on-position (yellow LED illuminated) when the measured voltage of all the phases exceeds the value adjusted at the MIN-regulator. When the measured voltage of one of the phases exceeds the value adjusted at the MAX-regulator, the set interval of the tripping delay (DELAY) begins (red LED MAX flashes). After the interval has expired (red LED MAX illuminated), the output relays switch into offposition (yellow LED not illuminated). The output relays again switch into on-position (yellow LED illuminated) when the measured voltage of all the phases falls below the value adjusted at the MAX-regulator (red LED MAX not illuminated). When the measured voltage of one of the phases falls below the value adjusted at the MIN-regulator, the set interval of the tripping delay (DELAY) begins again (red LED MIN flashes). After the interval has expired (red LED MIN illuminated), the output relays switch into off-position (yellow LED not illuminated).



If the fault latch is activated (WIN+LATCH) and the measured voltage of one of the phases remains below the MIN-value longer than the set interval of the tripping delay, the output relays remain in the off-position even if the measured voltage of all the phases exceeds the value adjusted at the MIN-regulator. If the measured voltage of one of the phases remains above the MAX-value longer than the set interval of the tripping delay, the output relays remain in the off-position even if the measured voltage of all the phases falls below the value adjusted at the MAX-regulator. After resetting the failure (interrupting and re-applying the supply voltage), the output relays switch into on-position and a new measuring cycle begins with the set interval of the start-up suppression (START).



Connections

G2YM400VL20 with power modul 24V AC without fault latch



G2YM400VL20 with power modul 230V AC with fault latch



G2YM400VL20 with power modul 400V AC without fault latch



Dimensions



RELEASE 2010/04

Subject to alterations and errors

